

## REGIS F – ACCESS or TIME AND ATTENDANCE CONTROLLER with INTEGRATED FINGERPRINT

The Regis is a controller with built-in fingerprint reader, proximity card reader and 3" LCD capacitive touch screen display. It is designed for residential and business buildings, offices, shops, etc. The controller can have 125kHz or 13.56MHz reading frequency. The entire set-up procedure is carried out with the software. The controller allows access for up to 500 fingerprints, 30000 users and saves 100000 events. If you bought the controller in time and attendance KIT, then inputs and outputs cannot be controlled. The SDK is also available for this controller. If a user or software producer wants to develop its own application, please contact us.

### TECHNICAL DATA

REGIS F	
REGIS F-1-B reading frequency	125kHz
REGIS F-1-B reading distance	Up to 10cm
REGIS F-1-9 current consumption in standby mode	200mA
REGIS F-3-B reading frequency	13.56MHz
REGIS F-3-B reading distance	Up to 7cm
REGIS F-3-B current consumption in standby mode	230mA
Dimensions (mm)	(WxHxD)
Protection	IP21
Operating voltage	From 9V to 14V DC
Operating temperature	From -20°C to 60°C
Display	3" TFT - resistive touch
Tamper	Accelerometer
Display resolution	400 x 240
Humidity	10-80%, non condensing
Memory	500 finger prints 30000 cards or codes 100000 events
Inputs	Door status Push button
Outputs	Transistor output for el. strike 0.5A
Clock	Real time clock, battery backup (max. ten hours)
Communication	RS485 Ethernet
Keypad	Configurable buttons and selectable colors - with Keypad Editor
Sensor protection	> 15kV ESD protection
Sensor usage	> 1 million wear cycles

### CONNECTOR DESCRIPTION

Contact	Description	Specification
1 - UIN	9-14V DC	Power supply
2 - GND	GND	Ground
3 - CA	CA - RS485	Communication line
4 - CB	CB - RS485	Communication line
5 - O0	El. strike output	Max. 0,5A When active = GND
6 - O1	Alarm output	When active = GND
7 - I0	Door status switch input	Active when connected to GND
8 - I1	Push button input	Active when connected to GND

### ETHERNET

Contact	Description	Specification	RJ45 connector
9 - TXP	Ethernet	TXP	1 - white/orange
10 - TXN	Ethernet	TXN	2 - orange
11 - RXP	Ethernet	RXP	3 - white/green
12 - RXN	Ethernet	RXN	6 - green

### Power supply

The controller needs external power supply to operate. The Spider W40 power supply is sufficient to power two controllers and two 12V electric strikes or two 12V magnetic locks (0.5A). If you will use it as a standalone controller and low consumption electric strike (0.25A) you can use power supply Spider W5.

### Voltage drops and cable signal interferences

When you connect the controller, use cable with a diameter of at least 0.22mm<sup>2</sup>. If the cable length exceeds 25m, use one twisted pair of UTP cables for the positive (+) pole and one for the negative (-) pole. The cable length between power supply and the controller should not exceed 50m.

Take into consideration that a 0.22mm<sup>2</sup> cable has a resistance of approximately 9 ohm per 100m. The power supply at the end of cable should be a minimum of 9V. If you are using el. strike, it is highly recommended that the voltage drop is calculated. At greater distances, a thicker cable of 0.5mm<sup>2</sup> or more should be used wherever possible.

If the load is, for example, 0.5A (with el. strike) then, on the 0.22mm<sup>2</sup> cable voltage drop will be 4.5V at 100m. For the device with 60mA consumption, the voltage drop is 0.5V.

Reading distance depends on where the controller is installed. The presence of metal or interferences can significantly reduce the reading distance. **DO NOT** install the controller directly on metal surfaces and/or cover it with a metal cover.

It is **not recommended** to install controllers closer than **30cm** from each other in any direction. Otherwise, it may result in inaccurate readings or, indeed, in the controller **not reading at all**.

**For the Regis F-3-B to comply with EMC directives (CE), you have to put ferrite core on the cable as close to the controller as possible, making two turns!**

### Inputs, outputs and environment

#### Inputs:

Inputs are realized with opto-isolators. The input is active, when pulled to ground with an open collector transistor or mechanical switch, which is connecting the input pin of the controller to the Ground.

#### Outputs:

Output has a pre-installed protection diode for an inductive load. It is also protected from current overload. The best way is to use a 0.25A el. strike or a 0.5A el. magnet, which has to be connected to the same positive pole (+) as the controller. Connect the negative pole (-) to the door strike output (wire 3). When the output is active it is pulled to ground. This can be changed with function 5 - negate output (for el. magnet).

#### Reading range:

The controller has a program algorithm that, at power start, sets parameters based on the installation environment, so as to ensure an optimal reading range. **DO NOT** install the controller directly on metal surfaces and/or cover it with a metal cover; it may stop working/reading. If you plan to test the controller and move it onto different surfaces, then you have to reset it (power off/on) on each surface.



**Environment:**

It is designed for indoor, non-condensing, applications. Do not expose the controller to direct contact with the elements such as rain, snow or sunlight. If the plastic housing is in a different color than black, then there is a chance that the color will change (to some extent) in a few months or years if exposed to direct sunlight. The sensor surface is hard and extremely robust, and will withstand years of normal wear-and-tear. Do not subject the sensor to sharp or hard objects since this might cause permanent damage. Cleaning should be done with a lint-free cotton textile. Do not subject the sensor surface to mechanical force. You must assure good cable joints, protected against moisture, otherwise corrosion may damage the controller. Damage in such cases is not covered by the warranty.

**Installation:**

Install the holder on the wall with two supplied screws. Use diagonal holes - it enables a small correction of the position of the controller (up, down, left, right). Connect wires to the controller and place it on the holder and press – after you hear the click, it is fixed. If you want to remove the controller from the holder, put the screwdriver into the side hole in push a little to move the pin holding the controller.

**AS AN ACCESS OR TIME AND ATTENDANCE CONTROLLER**

**Access controller**

As an access controller, it is intended for controlling entries, exits and passes of users in the system and controlling sliding doors, ramp, el. strike, turning alarm on/off... It needs to be set with CODEKS software.

Set the software according to your requirements (time tables, users...) and send the tables. The keypad will serve for entering user codes.

**Time and attendance controller**

As a time and attendance controller, it is intended to register the employee’s arrivals and exits from work, lunch break, private and business exits, sick leave... It needs to be set with CODEKS software. In software you need to choose option “Time and attendance” for controller and reader. Set the software according to your requirements (time tables, users...) and send the tables. The keypad will serve for choosing different time intervals (private, business...).

**The default address of the controller is the same as the last digit of the IP address. E.g. if the IP address of the controller is 192.168.110.105, then the controller’s address is 105.**

**If you have more controllers on the communication line, don’t duplicate addresses.**

**Communication**

**Ethernet:**

Connect the controller to the computer through your LAN via connector on the back side. Please check the connection scheme which can be found on Jantar Forum.

Use at least UTP CAT 5e cable. Adjust network settings of the controller using the Codeks Device Manager software so that it will function properly in your network. Please consult Codeks Device Manager’s manual.

**RS485:**

Connect the controller to the computer, with one of the power supplies, with communication converter, from the Spider family: Spider W5-USB, Spider W5-NET, Spider W40+NET. The RS485 communication bus is used between the controllers and Jantar software. Up to 128 controllers can be lined up into one communication line. The maximum length of the communication

line is 1000 cable meters. It is recommended that you use an FTP or S-FTP cable. Only a serial connection of controllers in a single

communication line is allowed. **Star (parallel) connection is not allowed.**

All shields of S-FTP cables must be wired together and at **one point** connected to the earth. Individual connections to the earth are not allowed. Do not connect the shield of the cable to the ground of the controller.

**In the event of problems in communication, a termination resistor needs to be added. We recommend using 120 Ohm resistors on each side of the cable. Converters are, on the RS485 side, protected with slow-blow fuses and transient voltage suppressors.**

**Changing back to standalone controller from access controller:**

In the Codeks Device Manager software do the “Brainwash” of the controller. Address of the controller’s switches back to 255.

**Correct and incorrect position of the finger on the sensor**

Correct:



Incorrect:



**ORDERING CODES**

**REGIS** [box]-[card]-[software]

Box: **F**

Card: **1** – reading frequency 125kHz (cards)

**3** – reading frequency 13.56MHz (cards)

Model: **B** – Black line

Code	Description
<b>REGIS F-1-B</b>	Standalone, access or time and attendance controller in <b>F</b> box, capacitive touch screen display, Frequency 125kHz, fingerprint reader for CODEKS software, Integrated Ethernet
<b>REGIS F-3-B</b>	Standalone, access or time and attendance controller in <b>F</b> box, capacitive touch screen display, Frequency 13.56MHz, fingerprint reader, for CODEKS software, Integrated Ethernet

**OTHER**

Warranty only applies when the controller Regis is used with power supply or/and communication converter from the Spider family.

Please read through our warranty and disclaimer statements.

Connection scheme and additional support for the use of this product can be found on:

<http://www.jantar.si/forum/en>

**CONTACT:**  
**Jantar d.o.o.**  
**Kranjska cesta 24**  
**4202 Naklo**  
**SLOVENIA**

**web:** [www.jantar.si](http://www.jantar.si)  
**mail:** [sales@jantar.si](mailto:sales@jantar.si)

